

*M. Dollo*

*IN-3-CR*

*07110*

*P-128*

**RoMPS Concept Review  
Automatic Control of Space Robot**

**NASA Goddard Space Flight Center**

**Prepared under NASA Grant NAG-5-1517**

**Environmental Research Institute of Michigan  
Space Automation & Robotics Center  
P.O.Box 134001  
Ann Arbor, Michigan 48113-4001**

**May 16, 1991**

(NASA-CR-168501) ROMPS CONCEPT REVIEW  
AUTOMATIC CONTROL OF SPACE ROBOT (CRIB)  
120 p CSCL 03P

N72-16851

Unclas  
07/83 0057110

## RoMPS Electrical & Software Systems Drawing Index

Rev: 5/14/91

Page	No.	Date	Title
0.1			Drawing Index, 1/n
0.2			Drawing Index, 2/n
0.3			Drawing Index, 3/n
1.0			RoMPS Concept
1.1			Carrier Options
1.2			System Block Diagram
1.3.1			AEMS Software Block Diagram
1.3.2			Zymate Software Block Diagram
1.4.1			Schedule Examples 1/6
1.4.2			Schedule Examples 2/6
1.4.3			Schedule Examples 3/6
1.4.4			Schedule Examples 4/6
1.4.5			Schedule Examples 5/6
1.4.6			Schedule Examples 6/6
1.5.1			Experiment Examples 1/3
1.5.2			Experiment Examples 2/3
1.5.3			Experiment Examples 3/3
2.0			Hitchhiker Interface Requirements Summary
2.1			Operations Timeline
2.2.1			Telemetry Formats 1/3
2.2.1			Telemetry Formats 2/3
2.2.1			Telemetry Formats 3/3
2.3			Command Format
2.4			Power Budget
2.5			Weight Budget
3.0			Robot Mechanism Axis Block Diagram
3.1.1			PMC Inc. Motion Controller System
3.1.2			PMC Inc. Command Summary
3.1.3			PMC Inc. MC200 Servo Controller Block Diagram
3.1.4			NEC $\mu$ PD7831-A 16-bit microcontroller
3.2.1			LM628629 Motion Controller IC (MC100 system)
3.2.2			LM628 Spec Summary
3.2.3			LM628 Analog Application
3.2.4			LM629 PWM Application
3.3			LM621 Brushless Motor Drive IC
3.4			AMC Inc. Servo Amplifier

*Noted*

## RoMPS Electrical & Software Systems Drawing Index

Rev: 5/14/91

Page	No.	Date	Title
4.0			Theta Axis
5.0			Z Axis
6.0			Radial Axis
7.0			Grip Axis
8.0			Force Sensing Block Diagram
8.0.1			Specification
8.0.2			Interface Summary
8.1			Force Sensing Amplifier - Typical
9.0			Autonomous Experiment System Manager Block Diagram
9.0.1			Specification
9.0.2			Interface Summary
10.0			Autonomous Experiment System Manager Data Flow Diagrams
10.1			Top Level
10.1.0			Level 0
10.1.2			Process Command Packet
10.1.4			Process System Directive
10.1.6			Format Telemetry Packet
10.1.10			Get Experiment Data
10.1.11			Process Experiment Directive
10.2			
10.3			EasyLab Command Structure
10.4			EasyLab Implementation Options
10.9.1			VRTX Multi-Tasking Real-Time System
10.9.2			VRTX Multi-Tasking Real-Time Kernel
11.0			Zymate Robot Controller Block Diagram
11.0.1			Specification
11.0.2			Interface Summary
12.0			Zymate Robot Controller Data Flow Diagrams
12.1			Top Level
12.1.0			Level 0
12.2.0			Main Control
12.2.1			Peripheral Control
13.0			SC-4 Spacecraft Computer
13.1			Specification
13.2			Block Diagram



## RoMPS Electrical & Software Systems Drawing Index

Rev: 5/14/91

Page	No.	Date	Title
14.0			Pyrometer Block Diagram
14.0.1			Specification
14.0.2			Interface Summary
15.0			Oven Control Block Diagram
15.0.1			Specification
15.0.2			Interface Summary
			<del>Typical Approach</del>
			PWM Controller
			<del>Interface</del>
16.0			Signal Conditioning Block Diagram
16.0.1			Specification
16.0.2			Interface Summary
16.1			Robot Thermistor Location
			YSI Linearized Calibration Curve
17.0			Power Distribution Block Diagram
17.0.1			Specification
17.0.2			Interface Summary
17.1			Grounding Diagram
			<del>DC Current Monitor</del>
18.0			Survival Heaters Block Diagram
15.0.1			Specification
15.0.2			Interface Summary
			Typical Circuit
19.0			Harness Block Diagram
20.0			SPRL Electronics Packaging
			Baseplate Assembly
			Stack Assembly
			Electronics Module Frame
			Stitchwire Board
			2 Sided PCB
21.0			Performance Assurance Program
21.1			Verification Plan
21.2			Component Qualification Plan

# System Concept

# GAS CAN CONCEPT LAYOUT







## ROMPS SYSTEMS OVERVIEW

OTE  
CODE 706


### CARRIER OPTIONS



HITCHHIKER-M




HITCHHIKER-G



# GAS Canister

# Support Electronics Assembly




ENGINEER	L. H. Tomko	DRAFTSMAN	X. X. XXXXXXXX
SPACE AUTOMATION & ROBOTICS CENTER			
ENVIRONMENTAL RESEARCH INSTITUTE of MI			
ANN ARBOR, MI			
System Block Diagram			
ROBOTS Concept			
ROBOPS			
XXXXXXX			
DATE			
05/14/91			



# AUTONOMOUS EXPERIMENT MANAGEMENT SYSTEM

SPARC  
A Robotics Center




PRECEDING PAGE BLANK NOT FILMED

SPARC 051491/MED1

131

ORIGINAL PAGE IS  
OF POOR QUALITY

# ZYMATE CONTROLLER





# ROMPS INITIAL CONFIGURATION


## EXPERIMENT - SCHEDULER




## SYSTEM DICTIONARY - RAM MEMORY




## LEARNED APPLICATION GOEMETERY



## MODULES - RAM MEMORY



## SYSTEM ROM



## SCENARIO-B

SCENARIO-A	EXPERIMENT_SETUP	ANNEALER.TIME(1) 10	END SAMPLE 5
10-OCT-92:09:00	PROCESS_METHOD_A	ANNEALER.TIME(1) 30	END SAMPLE 10
10-OCT-92:11:15	PROCESS_METHOD_B		
12-OCT-92:23:00	PROCESS_METHOD_B	ANNEALER.TIME(1) 50	END SAMPLE 50
12-OCT-92:23:45	EXPERIMENT.SHUTDOWN		

EXPERIMENT - SCHEDULER

ACTIVE\_SCHEDULE SCENARIO\_A

<CR>  
PROCESS\_METHOD\_A  
<CR>  
ANNEALER TIME (1) = 10  
<CR>

SCENARIO-B			
SCENARIO-A	EXPERIMENT_SETUP	PROCESS_METHOD_A	END SAMPLES
10-OCT-92:09:00	PROCESS_METHOD_A	ANNEALER TIME(1) 10	END SAMPLE 5
10-OCT-92:11:15	PROCESS_METHOD_B	ANNEALER TIME(1) 30	END SAMPLE 10
12-OCT-92:23:00	PROCESS_METHOD_B	ANNEALER TIME(1) 50	END SAMPLE 50
12-OCT-92:23:45	EXPERIMENT SHUTDOWN		

SYSTEM DICTIONARY - RAM MEMORY

PROCESS\_METHOD\_B

PROCESS\_METHOD\_A

GET\_FROM\_ANNEALER.A

PUT\_INTO\_ANNEALER.A

GET\_FROM\_ANNEALER.A

MOVE SAFE IN

MOVE ANNEALER ORIGIN A

OPEN HAND

...

...

...

ZYOS  
INTERPRETER

COMMAND VARIABLES  
ANNEALER TIME

LEARNED APPLICATION GOEMETRY

SAMPLE RACK.1	ABSOLUTE CYLINDRICAL COORDINATES	RACK INDEX
REL.IN.	RELATIVE COORDINATES	
...	...	...
...	...	...
...	...	...

MODULES - RAM MEMORY

ROBOT MODULE

ANNEALER MODULE

main (word robot

{

switch(command-id)

{

case(ANNEALER.A ON)

...

case(ANNEALER.A OFF)

...

case(ANNEALER.A TIMED)

}

}

SYSTEM ROM

PROCESS\_METHOD\_A

ROBOT MODULE

ANNEALER MODULE

# SHUTTLE PROBLEM CAUSE POSTPONEMENT OF OCT-12 EXPERIMENT

## EXPERIMENT-SCHEDULER

ACTIVE\_SCHEDULE SCENARIO-C

<CR>  
PROCESS\_METHOD\_B  
<CR>  
ANNEALER.TIME (1)=20  
<CR>

SCENARIO-B		SCENARIO-A		SCENARIO-C	
10-OCT-92:09:00	EXPERIMENT_SETUP	10-OCT-92:09:00	EXPERIMENT_SETUP	10-OCT-92:09:00	EXPERIMENT_SETUP
13-OCT-92:10:00	PROCESS_METHOD_B	13-OCT-92:10:00	PROCESS_METHOD_B	13-OCT-92:10:00	PROCESS_METHOD_B
13-OCT-92:12:00	EXPERIMENT_SHUTDOWN	13-OCT-92:12:00	EXPERIMENT_SHUTDOWN	13-OCT-92:12:00	EXPERIMENT_SHUTDOWN
ANNEALER.TIME (1)=20		ANNEALER.TIME (1)=20		ANNEALER.TIME (1)=20	
ENDSAMPLES		ENDSAMPLES		ENDSAMPLES	

LOAD NEW SCHEDULE

## SYSTEM DICTIONARY-RAM MEMORY

PROCESS\_METHOD\_B  
PROCESS\_METHOD\_A  
GET\_FROM\_ANNEALER.A  
MOVE.SAFE.IN  
MOVE.ANNEALER.ORIGIN.A  
OPEN.HAND  
...

ZYOS  
INTERPRETER

COMMAND VARIABLES  
ANNEALER.TIME

PUT\_INTO\_ANNEALER.A  
GET\_FROM\_ANNEALER.A  
MOVE.SAFE.IN  
MOVE.ANNEALER.ORIGIN.A  
OPEN.HAND  
...

## LEARNED APPLICATION GOEMETERY

SAMPLE RACK 1  
ABSOLUTE CYLINDRICAL COORDINATES  
REL.IN  
RACK INDEX  
RELATIVE COORDINATES



## MODULES-RAM MEMORY

ROBOT MODULE ANNEALER MODULE  
main (word robot  
(  
switch(command-id)  
{  
case(ANNEALER.A.ON)  
case(ANNEALER.A.OFF)  
case(ANNEALER.A.TIMED)  
})

## SYSTEM ROM

PROCESS METHOD A  
ROBOT MODULE  
ANNEALER MODULE

# EXPERIMENTERS DISCOVER ANOMALIES BETWEEN IDENTICAL SAMPLES PROCESSED IN OVEN A AND OVEN B: ) WANT LAST TWO PROCESS RUNS WITH NEW METHOD




COMMAND VARIABLES  
ANNEALER TIME

LEARNED APPLICATION GOEMETERY  
SAMPLE RACK.1 ABSOLUTE CYLINDRICAL COORDINATES  
REL.IN. RELATIVE COORDINATES  
RACK INDEX

## MODULES-RAM MEMORY



ROBOT MODULE ANNEALER MODULE  
main (word robot  
(  
switch(command-id)  
{  
case(ANNEALER.A.ON)  
:  
case(ANNEALER.A.OFF)  
:  
case(ANNEALER.A.TIMED)  
:  
})

## SYSTEM ROM



SCENARIO-B				
SCENARIO-A				
10-OCT-92:09:00	EXPERIMENT_SETUP	ANNEALER.TIME(1) 10	...	END SAMPLE 5
10-OCT-92:10:15	PROCESS_METHOD_A	ANNEALER.TIME(1) 30	...	END SAMPLE 10
10-OCT-92:11:15	PROCESS_METHOD_B	ANNEALER.TIME(1) 50	...	END SAMPLE 50
12-OCT-92:23:00	PROCESS_METHOD_B	EXPERIMENT SHUTDOWN		
12-OCT-92:23:45				

# ROBOT UNABLE TO GRAB SAMPLES FROM RACK LOAD NEW APPLICATION GOEMETRY




## SCENARIO - B


### SCENARIO - A

10-OCT-92:09:00	EXPERIMENT_SETUP	ANNEALER.TIME(1) 10	...	END SAMPLE 5
10-OCT-92:10:15	PROCESS_METHOD_A	ANNEALER.TIME(1) 30	...	END SAMPLE 10
10-OCT-92:11:15	PROCESS_METHOD_B	ANNEALER.TIME(1) 50	...	END SAMPLE 50
12-OCT-92:23:00	PROCESS_METHOD_B	EXPERIMENT.SHUTDOWN		
12-OCT-92:23:45				

# SINGLE STEP IMMEDIATE COMMAND MODE



## SYSTEM DICTIONARY-RAM MEMORY




COMMAND VARIABLES  
ANNEALER TIME


## LEARNED APPLICATION GOEMETRY

SAMPLE RACK 1	ABSOLUTE CYLINDRICAL COORDINATES	RACK INDEX
REL.IN	RELATIVE COORDINATES	

## MODULES-RAM MEMORY



## SYSTEM ROM



## SCENARIO-B

### SCENARIO-A

10-OCT-92:09:00	EXPERIMENT_SETUP	ANNEALER TIME(1) 10	END SAMPLE 5
10-OCT-92:10:15	PROCESS_METHOD_A	ANNEALER TIME(1) 30	END SAMPLE 10
10-OCT-92:11:15	PROCESS_METHOD_B	ANNEALER TIME(1) 50	END SAMPLE 50
12-OCT-92:23:00	PROCESS_METHOD_B	EXPERIMENT_SHUTDOWN	
12-OCT-92:23:45			



May 12 19:48 1991 process\_method\_a.zy Page 1

```

- EasyLabsLab program PROCESS_METHOD_A
- This procedure processes a samples START.SAMPLE to END.SAMPLE,
- using annealing oven a and the processing parameters contained in
- ANNEALER.TEMPS and ANNEALER.TIMES.

      - NOTE : WORKING.SAMPLE IS A LOCAL TYPE VARIABLE
      - THE START.SAMPLE IS ASSUMED TO BE SET BY THE CALLING
      - MODULE, THIS METHOD OF PARAMETER PASSING IS USED
      - THROUGHOUT THIS PROGRAM

WORKING.SAMPLE = START.SAMPLE

      - Get the sample to be processed
      - NOTE SAMPLE.RACK.1.INDEX IS USED BY THE ROBOT MODULE
      - TO DETERMINE THE SAMPLE WITHIN A RACK TO GET

SAMPLE.RACK.1.INDEX = WORKING.SAMPLE
GET.FROM.SAMPLE.RACK.1

      - put the sample in the annealer

PUT.INTO.ANNEALER.A

      - Set the temperature and time for the oven
      - and anneal the sample
      ANNEALER.A.TEMPERATURE = ANNEALER.TEMPS(WORKING.SAMPLE)
      ANNEALER.A.TIME = ANNEALER.TIMES(WORKING.SAMPLE)
      ANNEALER.A.TIMED.RUN

      - Get the sample from the annealer

GET.FROM.ANNEALER.A

      - Put the sample into the inspection station

PUT.INTO.INSPECTER

      - Measure the sample

OBTAIN.SAMPLE.PROPERTIES

      - Put Sample back into rack

PUT.INTO.SAMPLE.RACK.1

      - Determine if we have processed all the samples
WORKING.SAMPLE = WORKING.SAMPLE.1
IF WORKING.SAMPLE <= END.SAMPLE THEN 10

```

May 12 19:48 1991 process\_method\_b.zy Page 1

```
- EasyLabsLab program PROCESS_METHOD_A
- This procedure processes a samples START.SAMPLE to END.SAMPLE,
- using annealing oven b and the processing parameters contained in
- ANNEALER.TEMPS and ANNEALER.TIMES.
```

```
WORKING.SAMPLE = START.SAMPLE
```

```
- Get the sample to be processed
SAMPLE.RACK.1.INDEX = WORKING.SAMPLE
GET.FROM.SAMPLE.RACK.1
```

```
- put the sample in the annealer
PUT.INTO.ANNEALER.B
```

```
- Set the temperature and time for the oven
- and anneal the sample
ANNEALER.B.TEMPERATURE = ANNEALER.TEMPS(WORKING.SAMPLE)
ANNEALER.B.TIME = ANNEALER.TIMES(WORKING.SAMPLE)
ANNEALER.B.TIMED.RUN
```

```
- Get the sample from the annealer
GET.FROM.ANNEALER.B
```

```
- Put the sample into the inspection station
PUT.INTO.INSPECTER
```

```
- Measure the sample
OBTAIN.SAMPLE.PROPERTIES
```

```
- Put Sample back into rack
PUT.INTO.SAMPLE.RACK.1
```

```
- Determine if we have processed all the samples
WORKING.SAMPLE = WORKING.SAMPLE.1
IF WORKING.SAMPLE <= END.SAMPLE THEN 10
```

May 12 19:43 1991 process\_method\_c.zy Page 1

```
- EasyLabLab program PROCESS_METHOD_C
- This procedure processes a samples START.SAMPLE to END.SAMPLE,
- using annealing oven a and the processing parameters contained in
- ANNEALER.TEMPS and ANNEALER.TIMES. It processes the sample a second
- time using the same processing parameters but using oven b.
```

```
WORKING.SAMPLE = START.SAMPLE
    - This start the processing at the desired sample
```

```
SAMPLE.RACK.1.INDEX = WORKING.SAMPLE
GET.FROM.SAMPLE.RACK.1
    - Get the sample to be processed
```

```
PUT.INTO.ANNEALER.A
    - put the sample in the annealer
```

```
ANNEALER.A.TEMPERATURE = ANNEALER.TEMPS(WORKING.SAMPLE)
ANNEALER.A.TIME = ANNEALER.TIMES(WORKING.SAMPLE)
ANNEALER.A.TIMED.RUN
    - Set the temperature and time for the oven
    - and anneal the sample
```

```
GET.FROM.ANNEALER.A
    - Get the sample from the annealer
```

```
PUT.INTO.INSPECTER
    - Put the sample into the inspection station
```

```
OBTAIN.SAMPLE.PROPERTIES
    - Measure the sample
```

```
PUT.INTO.ANNEALER.B
    - put the sample in the annealer
```

```
ANNEALER.B.TEMPERATURE = ANNEALER.TEMPS(WORKING.SAMPLE)
ANNEALER.B.TIME = ANNEALER.TIMES(WORKING.SAMPLE)
ANNEALER.B.TIMED.RUN
    - Set the temperature and time for the oven
    - and anneal the sample
```

May 12 19:43 1991 process\_method\_c.zy Page 2

```
      - Get the sample from the annealer
GET.FROM.ANNEALER.B
      - Put the sample into the inspection station
PUT.INTO.INSPECTER
      - Measure the sample
OBTAIN.SAMPLE.PROPERTIES
      - Put Sample back into rack
PUT.INTO.SAMPLE.RACK.1
      - Determine if we have processed all the samples
WORKING.SAMPLE = WORKING.SAMPLE.1
IF WORKING.SAMPLE <= END.SAMPLE THEN 10
```

## Hitchhiker Interface Requirements

Robot TMA for static conditions

Power TMA yields dynamics via 15112 current sig  
which can be monitored for stop purposes

3 CPU ports -

Retain full dynamic control capabilities

Could be ported to Unix environment but -

should lose support

ROBOT  
TMS

~~GCSE~~ - health & safety

- limits

- "pieces" report

## Hitchiker Avionics Interface Requirements Summary

### Bilevel Commands (+28V)

- bus A/B select
- oven enable
- processor restart
- system halt

### Serial Command

NONE

### Asynchronous Uplink (RD)

- 1200 baud (1 start, 8 data, no parity, 1 stop )
- customer message - basic functions
  - operating system commands
  - experiment commands
- volume
  - TBD Bytes/Hour
- mission elapsed time (asynchronous or synchronous)

### Asynchronous Downlink (SD)

- 1200 baud (1 start, 8 data, no parity, 1 stop )
- customer data - basic content
  - operating system status
  - experiment status
- volume
  - TBD Bytes/Hour

### Medium Rate Downlink

NONE

### PCM Telemetry

NONE

### Analog Data

- Experiment Total Current

### Temperature Data

- SEA Baseplate
- GAS Structure
- GAS Heatsink

### IRIG-B MET

None

### 1 Minute Pulse

None

**Hitchiker Avionics Interface Requirements**  
**Telemetry Format**  
**1 Second Frame**

<u>Mnemonic</u>	<u>Description</u>	<u>Type</u>	<u>Len</u>	<u>Range</u>
SYNC	sync	byte	8	
SYNC	sync	byte	8	
SYNC	sync	byte	8	
ID	frame identification	byte	8	
SEC	sec	byte	8	0-59
MIN	min	byte	8	0-59
HOUR	hour	byte	8	0-11
UDAY	1's day	byte	8	0-9
TDAY	10's day	byte	8	0-3
	Manufacturing Control			
SLINE	schedule line number	byte	8	0-255
EXPID	experiment id	byte	8	0-255
ELINE	experiment line number	byte	8	0-255
SAMP	sample number	byte	8	0-255
	Manufacturing Process			
	pyrometer output	intg	16	
	sample temp	real	16	
	lamp intensity	real	16	
	lamp current	real	16	
	lamp voltage	real	16	
	Manufacturing Data			
	characterization output 1	real	16	
	characterization output 2	real	16	
	characterization output 3	real	16	
	characterization output 4	real	16	
	Robot Status			
	Z position	intg	16	
	Theta position	intg	16	
	Radial position	intg	16	
	Gripper position	intg	16	
	Radial force	real	16	
	Gripper force	real	16	
<hr/>				
Total Bytes				

# Hitchiker Avionics Interface Requirements

## Telemetry Format

### 1 Minute Frame

Mnemonic	Description	Type	Len	Range
SYNC	sync	byte	8	
SYNC	sync	byte	8	
SYNC	sync	byte	8	
ID	frame identification	byte	8	
	Manufacturing Calibration			
	pyrometer calibration	intg	16	
	pyrometer calibration	intg	16	
	pyrometer calibration	intg	16	
	pyrometer calibration	intg	16	
	Operating System			
OPSTAT	processor status	byte	16	
OSSTAT	software status	byte	16	
	Robot Controller			
CPSTAT	processor status	byte	16	
CSSTAT	software status	byte	16	
	Current Monitors			
ZMIMON	Z motor	real	8	0-tbd amp
TMIMON	Theta motor	real	8	0-tbd
RMIMON	Radial motor	real	8	0-tbd
GMIMON	Gripper motor	real	8	0-tbd
CPU1IMON	processor 1	real	8	0-1
CPU2IMON	processor 2	real	8	0-1
	Temperature Monitors - Support Electronics Assembly			
PWRTMP	power distribution	real	8	-20 +60 °C
CPU1TMP	processor 1	real	8	-20 +60
CPU2TMP	processor 2	real	8	-20 +60
	Temperature Monitors - Get Away Special Container			
BPTMP	baseplate	real	8	-20 +60
RADTMP	radiator	real	8	-20 +60
OV1TMP	lamp 1	real	8	-20 +60
OV2TMP	lamp 2	real	8	-20 +60
ROBTMP	robot	real	8	-20 +60
Total Bytes				



**Hitchiker Avionics Interface Requirements**  
**Telemetry Format**  
**Alternate 1 Second Frame**

<b>Mnemonic</b>	<b>Description</b>	<b>Type</b>	<b>Len</b>	<b>Range</b>
SYNC	sync	byte	8	
SYNC	sync	byte	8	
SYNC	sync	byte	8	
ID	frame identification	byte	8	
	<b>Operating System</b>			
OPSTAT	processor status	byte	16	
OSSTAT	software status	byte	16	
	<b>Robot Controller</b>			
CPSTAT	processor status	byte	16	
CSSTAT	software status	byte	16	
	Data Field	byte	16	
<hr/>				
Total Bytes				

## Hitchiker Avionics Interface Requirements

### Asynchronous Command RD

### Customer Message

- RoMPS payload command blocks will require one or more customer message packets.

Embedded within the HH specified customer message format will be a customer specified, generated and on-orbit processed command block protocol.

- Contents of customer data in customer messages:

customer protocol bytes

ASCII Strings (high level experiment language) or Binary Data (processor load)  
terminator

### PRELIMINARY

- User Interface Examples:

The schedule might look like this

DAY	GMT	EXP
-----	-----	-----

1	1300	01
1	1320	02
1	1900	05
2	2000	04

The contents of Experiment 01 might look like this:

WHILE

N>10 .and. N<=20

DO

MOVE.SAMPLE.N.OVEN

PROCESS.N.OVEN.NORMAL

END

ENDWHILE

However, for engineering purposes the language supports the following:

MOVE.AXIS.name.position

STEP.axis.dir.distance.rate

## Robot Axis Control Concepts


20,70 - remain full 2x real time compatible  
could port to single CPU/RT - plus numerous 's.

True one of several implementation options  
choice is to remove control/algorithm  
& proceed to limit ~~the~~ hardware

reg's system design considerations  
to minimize change while retaining  
real-time


STD BUS, UART, VME, ...  
Intel, NEC, 6800X CPU for controller (core of  
TE for SSD (expensive to port))

# Typical Robot Axis Mechanism



ORIGINAL PAGE IS  
OF POOR QUALITY

ENGINEER	I. M. Tomko	DRAFTSMAN	X. X. XXXXXXXX	XX/XX/XX
SPACE AUTOMATION & ROBOTICS CENTER		Robot Mechanism Axis Block Diagram		XX/XX/XX
ENVIRONMENTAL RESEARCH INSTITUTE OF MI		ROMPS		05/14/91
ANN ARBOR, MI		XXXXXXXXXXXX		DATE



ENGINEER	GLE DOBBS	DRAFTSMAN	X X XXXXXX	XX/XX/XX
SPACE AUTOMATION & ROBOTICS CENTER		PHIC Inc. Motion Controller	XX/XX/XX	XX/XX/XX
ENVIRONMENTAL RESEARCH INSTITUTE of MI		Robot Mechanism Axis Block Diagram	XX/XX/XX	XX/XX/XX
ANN ARBOR, MI		ROMPS	05/14/91	DATE
		XXXXXXXXXXXX		

3.1.1

## Sequence Commands

RC	Reset Counter
RT	Reset set
SA	Set Acceleration
SD	Set Derivative gain
SG	Set prop. Gain of motor
SI	Set Integral gain of DC servo or
	Set Initial pulse rate of stepper
SQ	Set torque
SV	Set Velocity
VG	Set Velocity Gain

IP	Interrupt on absolute Position
IR	Interrupt on Relative position
RP	RePeat
WA	Wait (time)
WE	Wait for Edge
WP	Wait for absolute Position
WR	Wait for Relative position
WS	Wait for Stop

## Register Command

AA	Accumulator Add
AC	Accumulator Complement, bit wise
AE	Accumulator logical Exclusive or with $n$ , bit wise
AI	Accumulator load Indirect
AL	Accumulator Load with constant $n$
AN	Accumulator logical aNd with $n$ , bit wise
AO	Accumulator logical Or with $n$ , bit wise
AR	copy Accumulator to Register $n$
AS	Accumulator Subtract
RB	Read Byte
RL	Read Long at absolute memory location $n$ into accumulator
RW	Read Word at absolute memory location $n$ into accumulator
SL	Shift Left -accumulator $n$ bits
SR	Shift Right accumulator $n$ bits
TR	Tell contents of Register $n$
	Tell contents of accumulator (register O)
WB	Write accumulator low Byte to absolute memory location $n$
WL	Write accumulator Long to absolute memory location $n$
WW	Write accumulator low Word to absolute memory location $n$

## Learn Mode Commands

AP	Adjust Position
LI	Learn position Incrementing
LP	Learn Position
LT	Learn Target
MI	Move to point, Incrementing
MP	Move to Point

### Reporting Commands

CC Current Count  
 CS Check Sum  
 HE Help  
 TA Tell Analog to digital converter  
 TD Tell Derivative gain  
 TF Tell Following error  
 TG Tell position Gain  
 TI Tell Integral gain of DC servo or  
 TL Tell Initial pulse rate of stepper  
 TP Tell Integration Limit  
 TS Tell Position  
 TT Tell Status  
 TV Tell Target  
 VE Tell Velocity  
 VE Tell VErsion

### Contouring Mode Commands

CM Contouring Mode

### Miscellaneous Commands


BK Break  
 DM Decimal Mode  
 HM Hexidecimal Mode  
 NO No Operation  
 SB Select Bank

### Macro Commands

EM Execute Macro  
 MC Macro Command  
 MD Macro Definition  
 RM Reset Macros  
 TM Tell Macros







NO.	DESCRIPTION	QTY	UNIT	PRICE	TOTAL
1	1000	1	1000	1.00	1.00
2	2000	1	2000	2.00	2.00
3	3000	1	3000	3.00	3.00
4	4000	1	4000	4.00	4.00
5	5000	1	5000	5.00	5.00
6	6000	1	6000	6.00	6.00
7	7000	1	7000	7.00	7.00
8	8000	1	8000	8.00	8.00
9	9000	1	9000	9.00	9.00
10	10000	1	10000	10.00	10.00
11	11000	1	11000	11.00	11.00
12	12000	1	12000	12.00	12.00
13	13000	1	13000	13.00	13.00
14	14000	1	14000	14.00	14.00
15	15000	1	15000	15.00	15.00
16	16000	1	16000	16.00	16.00
17	17000	1	17000	17.00	17.00
18	18000	1	18000	18.00	18.00
19	19000	1	19000	19.00	19.00
20	20000	1	20000	20.00	20.00
21	21000	1	21000	21.00	21.00
22	22000	1	22000	22.00	22.00
23	23000	1	23000	23.00	23.00
24	24000	1	24000	24.00	24.00
25	25000	1	25000	25.00	25.00
26	26000	1	26000	26.00	26.00
27	27000	1	27000	27.00	27.00
28	28000	1	28000	28.00	28.00
29	29000	1	29000	29.00	29.00
30	30000	1	30000	30.00	30.00
31	31000	1	31000	31.00	31.00
32	32000	1	32000	32.00	32.00
33	33000	1	33000	33.00	33.00
34	34000	1	34000	34.00	34.00
35	35000	1	35000	35.00	35.00
36	36000	1	36000	36.00	36.00
37	37000	1	37000	37.00	37.00
38	38000	1	38000	38.00	38.00
39	39000	1	39000	39.00	39.00
40	40000	1	40000	40.00	40.00
41	41000	1	41000	41.00	41.00
42	42000	1	42000	42.00	42.00
43	43000	1	43000	43.00	43.00
44	44000	1	44000	44.00	44.00
45	45000	1	45000	45.00	45.00
46	46000	1	46000	46.00	46.00
47	47000	1	47000	47.00	47.00
48	48000	1	48000	48.00	48.00
49	49000	1	49000	49.00	49.00
50	50000	1	50000	50.00	50.00
51	51000	1	51000	51.00	51.00
52	52000	1	52000	52.00	52.00
53	53000	1	53000	53.00	53.00
54	54000	1	54000	54.00	54.00
55	55000	1	55000	55.00	55.00
56	56000	1	56000	56.00	56.00
57	57000	1	57000	57.00	57.00
58	58000	1	58000	58.00	58.00
59	59000	1	59000	59.00	59.00
60	60000	1	60000	60.00	60.00
61	61000	1	61000	61.00	61.00
62	62000	1	62000	62.00	62.00
63	63000	1	63000	63.00	63.00
64	64000	1	64000	64.00	64.00
65	65000	1	65000	65.00	65.00
66	66000	1	66000	66.00	66.00
67	67000	1	67000	67.00	67.00
68	68000	1	68000	68.00	68.00
69	69000	1	69000	69.00	69.00
70	70000	1	70000	70.00	70.00
71	71000	1	71000	71.00	71.00
72	72000	1	72000	72.00	72.00
73	73000	1	73000	73.00	73.00
74	74000	1	74000	74.00	74.00
75	75000	1	75000	75.00	75.00
76	76000	1	76000	76.00	76.00
77	77000	1	77000	77.00	77.00
78	78000	1	78000	78.00	78.00
79	79000	1	79000	79.00	79.00
80	80000	1	80000	80.00	80.00
81	81000	1	81000	81.00	81.00
82	82000	1	82000	82.00	82.00
83	83000	1	83000	83.00	83.00
84	84000	1	84000	84.00	84.00
85	85000	1	85000	85.00	85.00
86	86000	1	86000	86.00	86.00
87	87000	1	87000	87.00	87.00
88	88000	1	88000	88.00	88.00
89	89000	1	89000	89.00	89.00
90	90000	1	90000	90.00	90.00
91	91000	1	91000	91.00	91.00
92	92000	1	92000	92.00	92.00
93	93000	1	93000	93.00	93.00
94	94000	1	94000	94.00	94.00
95	95000	1	95000	95.00	95.00
96	96000	1	96000	96.00	96.00
97	97000	1	97000	97.00	97.00
98	98000	1	98000	98.00	98.00
99	99000	1	99000	99.00	99.00
100	100000	1	100000	100.00	100.00


PRECEDING PAGE BLANK NOT FILMED

ORIGINAL PAGE IS OF POOR QUALITY



## Block Diagram

- ## Features
- o Complete single-chip microcomputer
    - 16-bit ALU
    - 8K ROM (µPD78312A only)
    - 256 bytes RAM
    - 1-bit and 8-bit logic
  - o Instruction prefetch queue
  - o 16-bit unsigned multiply and divide
  - o String instructions
  - o Memory expansion
    - 8085A bus-compatible
    - Total 6-K address space
  - o Large I/O capacity: up to 32 I/O port lines
  - o Extensive timer/counter system
    - Two 16-bit up/down counters
    - Quadrature counting
    - Two 16-bit timers
    - Free-running counter with two 16-bit capture registers
    - Pulse-width modulated outputs
    - Timebase counter
  - o Four-channel 8-bit A/D converter
  - o Two 4-bit real-time output ports
  - o Two nonmaskable interrupts
  - o Eight hardware priority interrupt levels
  - o Macroservice facility for interrupts gives the effect of eight CMA channels
  - o Bidirectional serial port
    - Either UART or interface mode
    - Dedicated baud rate generator
  - o Watchdog timer
  - o Refresh output for pseudostatic RAM
  - o Programmable HALT and STOP modes
  - o One-byte call instruction
  - o On-chip clock generator
  - o CMOS silicon gate technology
  - o +5-volt power supply



ENGINEER	ME DDDDS	DRAFTSMAN	X X XXXXXX	XX/XX/XX
SPACE AUTOMATION & ROBOTICS CENTER		NEC UPD7831XA 16-bit microcontroller		
ENVIRONMENTAL RESEARCH INSTITUTE of MI		Robot Mechanism Axis Block Diagram		
		RDPS		
ANN ARBOR, MI		XXXXXXXXXXXX		
		DATE		

## Features

- 32-bit position, velocity, and acceleration registers
- Programmable digital PID filter with 16-bit coefficients
- Programmable derivative sampling interval
- 8- or 12-bit DAC output data (LM628)
- 8-bit sign-magnitude PWM output data (LM629)
- Internal trapezoidal velocity profile generator
- Velocity, target position, and filter parameters may be changed during motion
- Position and velocity modes of operation
- Real-time programmable host interrupts
- 8-bit parallel asynchronous host interface
- Quadrature incremental encoder interface with index pulse input




FIGURE 1. Typical System Block Diagram


TL/H/9219-1

ENGINEER	ME Dobbs	DRAFTSMAN	X. X. XXXXXX	XX/XX/XX
SPACE AUTOMATION & ROBOTICS CENTER				XX/XX/XX
ENVIRONMENTAL RESEARCH INSTITUTE of MI				XX/XX/XX
ANN ARBOR, MI				05/14/91
XXXXXXXXXXXX				DATE

TABLE I. System Specifications Summary

Position Range	-1,073,741,824 to 1,073,741,823 counts
Velocity Range	0 to 1,073,741,823/216 counts/sample; ie, 0 to 16,383 counts/sample, with a resolution of 1/216 counts/sample
Acceleration Range	0 to 1,073,741,823/216 counts/sample; ie, 0 to 16,383 counts/sample, with a resolution of 1/216 counts/sample
Motor Drive Output	LM628: 8-bit parallel output to DAC, or 12-bit multiplexed output to DAC LM629: 8-bit PWM sign/magnitude signals
Operating Modes	Position and Velocity
Feedback Device	Incremental Encoder (quadrature signals; support for index pulse)
Control Algorithm	Proportional Integral Derivative (PID) (plus programmable integration limit)
Sample Intervals	Derivative Term: Programmable from 2048/f <sub>CLK</sub> to (2048 * 256)/f <sub>CLK</sub> in steps of 2048/f <sub>CLK</sub> (256 to 65,536 $\mu$ s for an 8.0 MHz clock). Proportional and Integral: 2048/f <sub>CLK</sub>

ENGINEER	M.E. Dobbs	DRAFTSMAN	X. X. XXXXXX	XX/XX/XX
SPACE AUTOMATION & ROBOTICS CENTER		LM628 Spec Summary		XX/XX/XX
ENVIRONMENTAL RESEARCH INSTITUTE OF MI		Robot Mechanism Axis Block Diagram		XX/XX/XX
ANN ARBOR, MI		RevIPS		05/14/91
		XXXXXXXXXXXX		DATE



**\*DAC offset must be adjusted to minimize DAC linearity and monotonicity errors. See text**

**FIGURE 14. Interfacing a 12-Bit DAC and LM628**

ENGINEER	ME Dobbs	DRAFTSMAN	X X XXXXXX	XX/XX/XX
SPACE AUTOMATION & ROBOTICS CENTER		LM628	Analog Application	XX/XX/XX
ENVIRONMENTAL RESEARCH INSTITUTE of MI		Robot Mechanism Axis Block Diagram		XX/XX/XX
ANN ARBOR, MI		RompS		05/14/91
		XXXXXXXXXXXX		DATE





FIGURE 17. PWM Drive for Brushless Motors

ENGINEER	ME Dobbs	DRAFTSMAN	X. X. XXXXXX	XX/XX/XX
SPACE AUTOMATION & ROBOTICS CENTER		LM629 PWM Application		XX/XX/XX
ENVIRONMENTAL RESEARCH INSTITUTE of MI		Robot Mechanism Axis Block Diagram		XX/XX/XX
ANN ARBOR, MI		Rohms		05/14/91
		XXXXXXXXXXXX		DATE

# Connection Diagram






TL/H/8878-1

Order Number LM621N  
See NS Package Number N18A

ENGINEER	HL Dobbs	DRAFTSMAN	X X XXXXXX	XX/XX/XX
LM621 Brushless Motor Drive IC				XX/XX/XX
Robot Mechanism Axis Block Diagram				XX/XX/XX
RoMPS				05/14/91
XXXXXXXXXXXX				DATE








ENGINEER	L. M. Tomko	DRAFTSMAN	X X XXXXXXX	XX/XX/XX
SPACE AUTOMATION & ROBOTICS CENTER		Force Sense Block Diagram		
ENVIRONMENTAL RESEARCH INSTITUTE of MI		ROMPS		
ANN ARBOR, MI		XXXXXXXXXXXX		
		05/14/91		
		DATE		

## Typical Robot Axis Strain Gauge Amplifier



Very Linear, low noise strain gauge circuit.

The four strain gauge elements (R) and the amplifiers A1 and A2 form a bridge network. The differential connection between the bridge network and amplifier A3 virtually eliminates the offset errors in A1 and A2. Positive feedback through Rx makes the effective input impedance of A3 greater than  $1M\Omega$ . The high impedance is used to reduce amplifier loading effects on the bridge circuit. The effects of both input offset and positive feedback resistance are described by the formulas below.

Effect of Rx:  $V_o \approx 1/2 \cdot R2/R1 \cdot \Delta R/R \cdot V_{ref} \cdot (1 - R2/2R1)^{-1}$ ,  $R_a = \left\{ \begin{array}{l} -R \text{ Without Rx} \\ \Delta R \text{ Using Rx} \end{array} \right. \cdot R2$

Effect of Vio:  $V_o \approx 1/2 \cdot R2/R1 \cdot \Delta R/R \cdot [V_{ref} \cdot Vio(A1) \cdot Vio(A2)] \cdot [1 - R2/R1] \cdot Vio(A3)$

ENGINEER	L. M. Tomko	DRAFTSMAN	X. X. XXXXXX	XX/XX/XX
SPACE AUTOMATION & ROBOTICS CENTER		Force Sensing Amplifier-Typical		XX/XX/XX
ENVIRONMENTAL RESEARCH INSTITUTE OF MI		Force Sensing Block Diagram		XX/XX/XX
ANN ARBOR, MI		ROMPS		05/14/91
		XXXXXXXXXXXX		DATE

# Autonomous Experiment Management System

Zymate Robot Controller

Southwest SC-4 Computer


\* Schedule req'd for autonom./prod. environment

Not avail in Zymate to extent req'd  
by typical spacecraft and system constraints.

(Action - no change to Zymate)

\* Cost real low, free of charge today & tomorrow


# AUTONOMOUS CONTROLLER



ENGINEER	HE Dobbs	DRAFTSMAN	X X XXXXX	XX/XX/XX
SPACE AUTOMATION & ROBOTICS CENTER		Autonomous Experiment System		XX/XX/XX
ENVIRONMENTAL RESEARCH INSTITUTE of MI		Manager Block Diagram		XX/XX/XX
ANN ARBOR, MI		R0015		05/14/91
		XXXXXXXXXXXX		DATE


Top Level

romps: level top




Level 0

romps: level 0



## Process Command Packet


romps: level 2






Format Telemetry Packet

romps: level 4




Get Experiment Data

romps: level 6





# Process Experiment Data

romps: level 10



## romps: level 11





\*Not supported in SC-4 port.

SpARC 051491/MC1.0

# IMPLEMENTATION OPTIONS FOR THE ROBOT MOVEMENT EasyLab™ Language Interface.

## PUT.INTO.ANNEALER

MOVE.IN.SAFE  
MOVE.ANNEALER  
MOVE.BELOW.ANNEALER  
MOVE.UP.INTO.ANNEALER

This implementation uses a set of "learned" absolute and relative positions. This method is supported and available in the current EasyLab™.  
NOTE : As these positions are stored in the system data dictionary their values can be modified.

S:ALL.SPEED = 1.0  
S:THETA= SAFE.RADIAL  
S:RADIAL = ANNEALER.RADIAL  
S:Z= ANNEALER.HEIGHT  
S:THETA = S:THETA +  
ANNEALER.THETA  
S:HEIGHT = UP.TO.ANNEALER

This implementation uses EasyLab™ Command Variables. Assignment to these variables causes the variable state to change and an action to occur. Again, this is still a method used and supported by EasyLab™.


S:ALL.SPEED = 1.0  
S:THETA= SAFE  
MOVE.THETA  
S:RADIAL = ANNEALER.RADIAL  
S:Z= ANNEALER.HEIGHT  
MOVE.ALL  
S:THETA = S:THETA +  
ANNEALER.THETA  
MOVE.THETA  
S:HEIGHT = UP.TO.ANNEALER  
MOVE.HEIGHT

This implementation uses command variables in a different manner than the current EasyLab™ robot movement language.

Command variables do not cause the robot movement to occur. Instead, movement is initiated by a simple command which uses the previously set variable states as its inputs. This implementation would be easy to accomplish with the current EasyLab™ interpreter.


MOVE "THETA", ALL.SPEED,  
SAFE.THETA  
MOVE "RADIAL", ALL.SPEED,  
ANNEALER.RADIAL  
MOVE "Z", ALL.SPEED,  
ANNEALER.HEIGHT  
MOVE.REL "THETA", ALL.SPEED  
BELOW.ANNEALER  
MOVE.REL "THETA" .ALL.SPEED,  
UP.ANNEALER

This implementation uses a currently unavailable zymate interpreter ability, parameter passing. There are no plans for this to be implemented in the port to the SC-4 system.



ENGINEER	GLE Dobbs	DRAFTSMAN	X X XXXXXX	XX/XX/XX
SPACE AUTOMATION & ROBOTICS CENTER		VRTX Multi-Tasking Real-Time System		XX/XX/XX
ENVIRONMENTAL RESEARCH INSTITUTE of MI		AESM Data Flow Diagrams		XX/XX/XX
ANN ARBOR, MI		RoMPS		05/14/91
		XXXXXXXXXXXX		DATE

# Software



# Hardware



VRTX32

User Supplied

Optional




ORIGINAL PAGE IS  
OF POOR QUALITY

ENGINEER	PIE DODDS	DRAFTSMAN	X X XXXXXX	XX/XX/XX
SPACE AUTOMATION & ROBOTICS CENTER			VRTX Multi-Tasking Real-Time Kernel	XX/XX/XX
ENVIRONMENTAL RESEARCH INSTITUTE OF MI			AESM Data Flow Diagrams	XX/XX/XX
ANN ARBOR, MI			Rorips	05/14/91
			XXXXXXXXXXXX	DATE




ROBOT CONTROLLER



ENGINEER	X X XXXXXX	DRAFTSMAN	X X XXXXXX	XX/XX/XX
SPACE AUTOMATION & ROBOTICS CENTER		Zymate Robot Controller Block Diagram		XX/XX/XX
ENVIRONMENTAL RESEARCH INSTITUTE of MI		RorIPS		XX/XX/XX
ANN ARBOR, MI		XXXXXXXXXXXX		05/14/91
				DATE


Top Level

zymate: level top




Level 0

zymate: level 0




# Main Control


## ZYMATE MAIN CONTROL PROGRAM



# Peripheral Control



## ZYMATE PERIPHERAL CONTROL PROGRAM





ORIGINAL PAGE IS  
OF POOR QUALITY

**Preliminary Specification**  
**SC-4 Single Board Spacecraft Computer**

Central Processor	80C186/80C187 16 Bit
Clock Frequency	10 MHz
Operating System	MS-DOS and VRTX Compatible
Onboard Memory	
RAM	512K Bytes w/EDC
EEPROM	256K Bytes
UVPROM	64K Bytes
Hardware Vectored Interrupts	16 User Configurable
Timer/Event Counters	6, Software Configurable, 120 ns Granularity
Input/Output Capability	
Parallel I/O	16 Input, 16 Output
Analog Input	32 Differen solution,
Analog Output	4 Channels
RS-422 Serial I/O	2 Channels
SCSI Interface	1 Port
Mass Storage	24M Bytes, F  olatile
Expansion	Internal Daug  ector
Size	7 X 12 X 2.25 in
Weight	5 Lb (Approximate)
Power	28v @ 5w (Approximate)






# Oven Control

## Housekeeping Data


PRECEDING PAGE BLANK NOT FILMED



ORIGINAL PAGE IS  
OF POOR QUALITY

ENGINEER J. STEVENS	DRAFTER E.J. REK	4/9/87
SPACE PHYSICS RESEARCH LABORATORY	IF THERMAL CONTROLLER	
COLLEGE OF ENGINEERING	BLOCK DIAGRAM	2/1/89
UNIVERSITY OF MICHIGAN	HRDI UARS PSE	3/15/88
ANN ARBOR, MICHIGAN	B-E8033	DATE
	CONTROLLED	


54.0



LAST USED R 17Z C 12Z DZ Q1 L 1/6




# GAS CAN CONCEPT LAYOUT



PRECEDING PAGE BLANK NOT FILMED

ORIGINAL PAGE IS  
OF POOR QUALITY


RESISTANCE VERSUS TEMPERATURE — 40° to +100°				
TEMP °C RES	TEMP °C RES	TEMP °C RES	TEMP °C RES	TEMP °C RES
-40 84.8K	-10 158.0K	+20 37.20K	+30 10.97K	+80 384.0
-38 78.0K	-8 142.5K	21 32.70K	21 10.57K	81 372.0
-37 72.9K	7 135.2K	23 32.71K	23 10.57K	83 348.0
-35 67.0K	5 128.5K	24 31.32K	24 9.850	84 337.8
-34 61.0K	4 116.0K	25 29.84K	25 9.165	85 327.3
-33 57.5K	3 110.2K	26 28.54K	26 8.482	86 316.8
-32 54.0K	2 104.5K	27 27.40K	27 7.800	87 307.5
-31 51.0K	1 98.80K	28 26.40K	28 7.118	88 297.9
-30 48.0K	0 94.88K	29 25.44K	29 6.436	89 288.7
-29 45.5K	-1 90.81K	30 24.52K	30 5.754	90 278.9
-28 42.5K	-2 86.09K	31 23.63K	31 5.072	91 269.2
-27 40.0K	-3 81.11K	32 22.78K	32 4.390	92 261.2
-26 37.5K	-4 76.44K	33 21.96K	33 3.708	93 253.2
-25 35.0K	-5 71.44K	34 21.17K	34 3.026	94 245.2
-24 32.5K	-6 66.55K	35 20.41K	35 2.344	95 240.2
-23 30.0K	-7 61.35K	36 19.68K	36 1.662	96 233.1
-22 27.5K	-8 56.55K	37 18.98K	37 1.380	97 226.2
-21 25.0K	-9 51.55K	38 18.30K	38 1.098	98 219.1
-20 22.5K	+0 46.75K	39 17.65K	39 .816	99 213.1
-19 20.0K	+1 42.07K	40 17.02K	40 .534	+100 206.9
-18 17.5K	+2 37.57K	41 16.41K	41 .252	
-17 15.0K	+3 33.24K	42 15.81K	42 .000	
-16 12.5K	+4 29.06K	43 15.23K	43 .250	
-15 10.0K	+5 25.00K	44 14.66K	44 .500	
-14 7.5K	+6 21.04K	45 14.11K	45 .750	
-13 5.0K	+7 17.28K	46 13.58K	46 .000	
-12 2.5K	+8 13.72K	47 13.06K	47 .250	
-11 0.0K	+9 10.36K	48 12.55K	48 .500	
-10 0.0K	+10 7.11K	49 12.05K	49 .750	
-9 0.0K	+11 4.07K	50 11.56K	50 1.000	



ENGINEER MDOBBS	DRAFTSMAN M F	6/10/87
SPACE PHYSICS RESEARCH LABORATORY		
COLLEGE OF ENGINEERING		
UNIVERSITY OF MICHIGAN		
ANN ARBOR, MICHIGAN		
B-E8154		CONTROLLED
TEMPERATURE ALGORITHMS 2 OF 2		6/10/87
INTERFEROMETER HOUSEKEEPING		
HRDI UARS		


ORIGINAL PAGE OF POOR QUALITY

LAST USED R C D L




PRECEDING PAGE SHOULD NOT BE RECD

ENGINEER M DOBBS	DRAFTSMAN M	6/30/87
SPACE PHYSICS RESEARCH LABORATORY		
COLLEGE OF ENGINEERING		
UNIVERSITY OF MICHIGAN		
ANN ARBOR, MICHIGAN		
B-E 8204		CONTROLLED
6/10/87		DATE



\* 1 %, 25ppm TEMP COEFFICIENT

TYPICAL BIAS CIRCUIT



PRECEDING PAGE BLANK NOT FILMED

ENGINEER	C.O. LEONARD	DRAFTSMAN	J.B.	4/24/83
SPACE PHYSICS RESEARCH LABORATORY		TEMP MONITORS		
COLLEGE OF ENGINEERING		INTERFEROMETER HOUSEKEEPING		
UNIVERSITY OF MICHIGAN		HR01 UARS		
ANN ARBOR, MICHIGAN		B-E7439 CONTROLLED		
LAST USED R16 C16 D L		DATE		
		8/21/86		
		1/6/86		
		23.3		



## Power Distribution

- Preliminary

- Issues

Run servos off +28 Bcs


W/ isolation by opto on FET gates

~~SS~~




TODO

~~single point~~ true gnd diagnosis

## SUPPORT ELECTRONICS ASSEMBLY



ENGINEER	H.E. Dobbs	DRAFTSMAN	X.X.XXXXXX	XX/XX/XX
SPACE AUTOMATION & ROBOTICS CENTER			Power Distribution Block Diagram	XX/XX/XX
ENVIRONMENTAL RESEARCH INSTITUTE of MI			ROHPS	05/14/91
ANN ARBOR, MI			XXXXXXXXXXXX	DATE




ENGINEER	I. M. Tomko	DRAFTSMAN	X X XXXXXX	XX/XX/XX
SPACE AUTOMATION & ROBOTICS CENTER		Grounding Diagram		XX/XX/XX
ENVIRONMENTAL RESEARCH INSTITUTE OF MI		Power Distribution Block Diagram		XX/XX/XX
ANN ARBOR, MI		RmPS		05/14/91
		XXXXXXXXXXXX		DATE

54.3.3



1) NE556 VCC@ 10-6.2 = 3.8  
GND@ -12+6.2 = 5.8  
9.6 TOTAL



SURVIVAL HEATER  
 44Ω EACH  
 MINCO HA7629  
 R9, R10, R11

ENGINEER	M. E. DOBBS	DRAFTSMAN R.K. J.B.	8/26/87
SPACE PHYSICS RESEARCH LABORATORY		RADIATOR WIRING	
COLLEGE OF ENGINEERING		INTERFEROMETER	
UNIVERSITY OF MICHIGAN		HRDI UARS	
ANN ARBOR, MICHIGAN		PAGE 2 OF 2	
LAST USED R C D L		B-E8272 CONTROLLED	

## Space Physics Research Laboratory Packaging Conventions

STD' Atomic Grade

Provides robust JRC - Fault History  
inexpensive, reliable

EWAL - minimal packaging effort

PRECEDING PAGE BLANK NOT FILMED

68.

**CONTROLLED**

ORIGINAL PAGE IS  
OF POOR QUALITY

**Interim Design Review**

**NASA Goddard Space Flight Center  
Robotic Material Processing System Program  
Automation Systems**

**18 October 1991**

**prepared by**

**Environmental Research Institute of Michigan  
Space Automation and Robotics Center  
P.O. Box 134001  
Ann Arbor, Michigan 48113-4001**



## **RoMPS General Mission Requirements**


- Rapid Thermal Annealing (RTA) in Microgravity
  - Microgravity material processing
  - High temperature annealing furnace
  - Automated RTA processing and sample change
- STS Hitchhiker Payload
  - GAS canister and HH avionics mounting plate
  - Class D payload classification
  - Serial command and telemetry
- Mission Characteristics
  - Operates during STS disturbance free "quiet" periods
  - Operational changes expected
    - reschedule operations to meet STS constraints
    - modification of RTA processing parameters

## Office of Commercial Programs Requirements

- Infrastructure - Enable Low Cost Space Manufacturing
  - new technology - patents, license, product sales
  - reduced cost-per-pound
    - reduce non-recurring engineering cost
    - use industrial practices and products
    - carrier independent systems
    - experiment independent systems
  - system architecture for manufacturing facility
- Closely Related OCP Infrastructure CCDS Flight Programs at SpARC
  - Autonomous Rendezvous & Docking
  - Autonomous Experiment Management System (AEMS)
    - Wake Shield Facility
  - Autonomous Experiment Management System (AEMS)
    - Robotic Substrate Servicing System
    - Satellite Servicing System
  - EPOP Control and Data System (AEMS)
  - LABS
    - Autonomous Experiment Management System (AEMS)
    - Material Handling Automation


## Automation Management System

- Schedule Scripts
  - STS operational timeline changes
  - Investigator sample priority changes
- Processing Scripts
  - process methodology changes
  - process parameter changes
- High Level Language User Interface
  - industry proven
  - put PI in the drivers seat
  - attempt transparent environment from laboratory to flight
- Automatic Control
  - automatic sample change
  - automatic process control
  - rule based error detection and resolution



6

# HITCHHIKER AVIONICS PLATE



<div> <div>HT</div> <div>RT</div> </div>	HITCHHIKER TEMPERATURE SENSOR	ENGINEER	M.F. DOBBS	DRAFTSMAN	G. WASSICK
	ROMPS TEMPERATURE SENSOR	SPACE AUTOMATION & ROBOTICS CENTER ENVIRONMENTAL RESEARCH INSTITUTE of M ANN ARBOR, MI			
		Block Diagram 2/2			
		SEA Subsystem			
		ROMPS			
		010-339			
		DATE			
		07/02/91			


7

# GAS CANISTER

RADIATOR



## Oven Assembly




## Robot Assembly

ROBOT Z-AXIS  
ROBOT R-AXIS  
ROBOT THETA-AXIS  
ROBOT GRIPPER AXIS

STACKS

## Electronics Stack B



SUPPORT  
ELECTRONICS  
ASSEMBLY

SERIAL

+28V

NAVTROL  
BUS

MONITORS  
TEMP  
SIGNALS

HITCHHIKER

TEMP  
SIGNALS

BASEPLATE

(HT) HITCHHIKER TEMPERATURE SENSOR

(RT) RoMPS TEMPERATURE SENSOR

ENGINEER M.E. DOBBS

SPACE AUTOMATION & ROBOTICS CENTER  
ENVIRONMENTAL RESEARCH INSTITUTE of M  
ANN ARBOR, MI

DRAFTSMAN G. WASSICK

Block Diagram 1/2  
GAS Canister Subsystem  
RoMPS  
010-342

07/02/91  
DATE

# SCL Scripts

- SCL scripts are similar to tasks or other stand alone programs.
- Scripts can be executed immediately by command directive.
- Scripts can also be scheduled for deferred execution. SCL supports:
  - Absolute execution times.
  - Relative execution times.
- Scripts can be scheduled for cyclic execution (repetitive execution).



## Experiment Spreadsheet

A	B	C	D	E	F	G	H	I
Run	Sample	Rack	Rack Index	Temperature 1	Time 1	Temperature 2	Time 2	Processed
1	1	1	1	410	90	410	90	N
2	2	1	2	410	90	410	90	N
3	3	1	3	410	90	410	90	N
4	4	1	4	410	90	410	90	N
5	5	1	5	410	90	410	90	N
6	6	1	6	410	90	410	90	N
7	7	1	7	350	90	350	90	N
9	...	...	...	...	...	...	...	...
10	...	...	...	...	...	...	...	...
11	...	...	...	...	...	...	...	...
12	...	...	...	...	...	...	...	...
13	141	6	5	400	30	400	30	N
14	142	6	6	200	30	200	30	N
15	143	6	7	400	5	400	5	N
16	144	6	8	400	15	400	15	N



21

4

```
-- SCL Scenario Script
```

```
--
```

```
-- Function Defines processing scenario for do_processing  
-- script.
```

```
script    experiment_scenario
```

```
run              = 1  
gSample[run]     = 1  
gRack[run]       = 1  
gRack_Index[run] = 1  
gTemperature1[run] = 410  
gTime1[run]      = 90  
gTemperature2[run] = 410  
gTime2[run]      = 90
```

```
run              = 2  
gSample[run]     = 2  
gRack[run]       = 1  
gRack_Index[run] = 2  
gTemperature1[run] = 410  
gTime1[run]      = 90  
gTemperature2[run] = 410  
gTime2[run]      = 90
```

```
...
```

```
...
```

```
run              = 144  
gSample[run]     = 144  
gRack[run]       = 6  
gRack_Index[run] = 8  
gTemperature1[run] = 200  
gTime1[run]      = 30  
gTemperature2[run] = 200  
gTime2[run]      = 30
```


```
end    experiment_scenario
```

# SCL Software Components

- The SCL software system is divided into 3 major components:
  - The Development Environment. The development environment provides tools for developing and maintaining scripts and rules and for controlling the operation of the system
  - The Real-Time Database. The database defines the SCL software's operating environment.
  - The Real-Time Engine (RTE). Executes the SCL scripts, rules, and command directives.



# SCL Software Data Flows



## SCL Real-Time Engine

- The Real-Time Engine (RTE) executes SCL scripts, rules and command directives.
- The RTE is portable:
  - Written in C and Ada
  - Application specific I/O and system service calls have been isolated and "abstracted" out the SCL software.
- The RTE is generic/reusable. SCL scripts and rules are used to tailor the system to a specific application.
- The RTE is dynamic. Scripts and rules can be added or deleted without changing the RTE and its underlying interface routines.



# **RoMPS EasyLab Command & Variable Summary for Rack Stations**

## **RACK.INDEX**

EasyLab variable used by RoMPS PyTechnology to determine the current sample for robot to manipulate. Initial Value is 1.

## **GET.FROM.RACK**

Get sample RACK.INDEX from its home rack and slot.

## **PUT.INTO.RACK**

Move the currently held sample into the home rack and slot of RACK.INDEX.

# **RoMPS EasyLab Command & Variable Summary for Annealer Module**

<b>ANNEALER.TEMPERATURE</b>	Output Command Variable used to set the target temperature for the next annealing initiated by ANNEALER.ON and ANNEALER.TIMED.RUN. Initial Value TBD.
<b>ANNEALER.TIME</b>	Output Command Variable used to set the annealing time for the next annealing initiated by ANNEALER.TIMED.RUN. Initial Value TBD.
<b>ANNEALER.RATE</b>	Output Command Variable used to set the heating rate for the next annealing initiated by ANNEALER.ON and ANNEALER.TIMED.RUN. Initial Value TBD.
<b>ANNEALER.ACTIVE.OVEN</b>	EasyLab variable used by the Annealer robot movement commands, to determine position to put and get samples.
<b>MOVE.UNDER.ANNEALER</b>	Move Robot Gripper Under Sample, Lined up to allow pallet to be inserted into annealer.
<b>PUT.INTO.ANNEALER</b>	Move sample up into Annealer After a MOVE.UNDER.ANNEALER command.
<b>ANNEALER.ON</b>	Initiate an untimed run of the Annealer.
<b>ANNEALER.OFF</b>	Terminate an untimed run of the Annealer.
<b>ANNEALER.TIMED.RUN</b>	Initiate a timed run of the Annealer.

16

~~16~~

## Automation Management System

- Architecture Demonstrated at SpARC on 4 October 1991

### SC4 #1 with SCL implements

generic - scheduler  
specific - carrier i/o

### SC4 #2 with EASYLAB implements

generic - sample handling, processing  
specific - robot geometry

### Electronics

generic - servos, housekeeping  
specific - interfaces

- Status
  - MOU's in place
  - License agreements outlined
  - DFD's prepared
  - Elements to be designed have models to work from
- Long Term Architecture
  - Multiple robot and process space manufacturing facility
- Minimize Lifecycle Costs
  - Industrial development, support, maintenance and documentation

## RoMPS Electronics Assemblies

- Support Electronics Assembly

Mounted to Hitchhiker Adapter Plate

Integrated assembly with common support plate and cover

Connector Bracket

Power Distribution

SwRI SC4 Computer #1

SwRI SC4 Computer #2

Navtrol DDSC Master

- GAS Electronics Assembly

Mounted inside 5" GAS Extension

Integrated assembly with common support plate

Connector Brackets

Power Distribution

Navtrol DDSC Slave #1

Navtrol DDSC Slave #2



Navtrol DDSC Slave #3

Thermocouple Signal Conditioning

Data Acquisition



# SUPPORT ELECTRONICS ASSEMBLY



ENGINEER	R. E. QUADA	DRAFTSMAN	S. J. CARR
SPACE AUTOMATION & ROBOTICS CENTER		LAYOUT	
ENVIRONMENTAL RESEARCH INSTITUTE of MI		SUPPORT ELECTRONICS ASSEMBLY	
ANN ARBOR, MI		DATE	
		10/09/91	

10000 # 6100

Due


✓✓✓✓✓

## RoMPS Elec Weight &amp; Power

	A	B	C	D	E	F	G	H
1	RoMPS Weight & Power							
2	Assembly	Subassembly	Mfgr	Size LWH in	Mass lbs	Avg Pwr	Peak Pwr	Comments
3								
4	Support Elect	mount plate	GSFC		tbd			
5	Assembly	emi cover	GSFC		tbd			
6		SC-4	SwRI	7.25x12.25x2	3.7	5	5	
7		SC-4	SwRI	7.25x12.25x2	3.7	5	5	
8		HH I/O	ERIM	7 x 7 x 0.75	1.1	1	1	
9		HHPWR	ERIM	7 x 7 x 1.25	1.1	0	0	
10		DDSC Master	Navtrol	4.5x5.1x1	2	3.7	3.7	
11		connec. brack	ERIM		tbd			
12		harness	ERIM		tbd			
13		hardware			tbd			
14								
15		SUBTOTAL			11.6	14.7		
16								
17	GAS Electroni	mount plate	GSFC	17.5 dia	tbd			
18	Assembly	DDSC	Navtrol	4.5x5.1x1	2	3.7	269	9.6a worst ca
19		DDSC	Navtrol	4.5x5.1x1	2	3.7		one axis only
20		DDSC	Navtrol	4.5x5.1x1	2	3.7		one axis only
21		Housekeeping	ERIM	7x7x0.75	1.1	3	5	logic
22		Housekeeping	ERIM	7x7x0.75	1.1	2	5	analog
23		Power Dist	ERIM	7x7x1.25	2.2	2	2	converter los
24		connec.bracke	ERIM		tbd			
25		harness	ERIM		tbd			
26		hardware			tbd			
27								
28		SUBTOTAL			10.4	18.1		
29								
30		TOTAL			22	32.8		

20A

# HITCHHIKER AVIONICS PLATE




- (HT) HITCHHIKER TEMPERATURE SENSOR
- (RT) RoMPS TEMPERATURE SENSOR

ENGINEER	M.E. DOBBS	DRAFTSMAN	G. WASSICK
SPACE AUTOMATION & ROBOTICS CENTER		Block Diagram 2/2	
ENVIRONMENTAL RESEARCH INSTITUTE of MI		SEA Subsystem	
ANN ARBOR, MI		RoMPS	
		07/02/91	
		DATE	
		010-339	

## Hitchhiker Interface Subsystem

- Flight Hardware
  - power switching and bus protection
  - serial interface receivers and drivers
  - HH command packet protocol processing
  - telemetry packet generation
  - health and safety monitors
- Ground Support Equipment & Operations Console
  - customer ground support equipment
  - command generation
  - script development
  - process development
  - telemetry processing
  - archiving
  - engineering unit conversion
  - parameter limit checking
  - investigator operations console


# SUPPORT ELECTRONICS ASSEMBLY



+ 28 V BUS A      + 28 V BUS B


## GAS CAN ASSEMBLY

ENGINEER	M. E. Dobbs	DRAFTSMAN	
	SPACE AUTOMATION & ROBOTICS CENTER	SEA	
	ENVIRONMENTAL RESEARCH INSTITUTE of MI	Power Distribution Block Diagram	10/10/91
	ANN ARBOR, MI	ROMPS	05/14/91
		010-341	DATE



ENGINEER	M. F. DORBS	DRAFTSMAN	
SPACE AUTOMATION & ROBOTICS CENTER		GAS Can Assembly	
ENVIRONMENTAL RESEARCH INSTITUTE of MI		Power Distribution Block Diagram	
ANN ARBOR, MI		R&MPS	
		DATE	
		010-345	


# SCL Uplink Packet Definition





# RoMPS Telemetry

	A	B	C	D	E
1	RoMPS Telemetry				
2	Function	Description	Length	Rate	Comment
3					
4	Frame Header	sync	2	1	
5		sync/id	2	1	
6					
7	RTE Packet	id, etc	2	1	
8		rte state	2	1	
9		agenda status	2	1	
10		script status	10	1	
11		script status	10	1	
12					
13	DUMP Packet	id/len	4	1	
14		sample id	2	1	
15		process id	2	1	
16		sample temp	2	1	
17		lamp intensit	2	1	
18		lamp intensit	2	1	
19		lamp intensit	2	1	
20		lamp intensit	2	1	
21		lamp current	2	1	
22		elevation	2	1	
23		theta	2	1	
24		radial	2	1	
25		grip	2	1	
26		force	2	1	
27		exp. current	2	1	
28		eot status	2	1	
29		error reports	10	1	5 maximum
30		housekeeping	16	1	8 maximum
31					
32	TOTAL		90		
33	BUDGET		120		1200 baud



ORIGINAL PAGE IS  
OF POOR QUALITY

ENGINEER	DRAFTSMAN	
SPACE AUTOMATION & ROBOTICS CENTER ENVIRONMENTAL RESEARCH INSTITUTE of MI ANN ARBOR, MI		08/08/91
		DATE
		010-132



TABLE 1.2.2-1

Preliminary Specification  
SC-4 Single Board Spacecraft Computer

Central Processor	80C186/80C187 16 Bit
Clock Frequency	10 MHz
Operating System	MS-DOS and VRTX Compatible
Onboard Memory	
RAM	512K Bytes w/EDC
EEPROM	256K Bytes w/EDC
UVPR0M	640K Bytes w/EDC
Hardware Vectored Interrupts	16 User Configurable
Timer/Event Counters	8, Software Configurable, 120 ns Granularity
Input/Output Capability	
Parallel I/O	16 Input, 16 Output
Analog Input	32 Channels, 12-bit Resolution
Analog Output	4 Channels, 12-bit Resolution
RS-422 Serial I/O	2 Channels
SCSI Interface	1 Port
Software Controlled Power Switch	4 Each
Mass Storage	24M Bytes, Read/Write Non-volatile with Additional Battery
Expansion	Internal Daughterboard Connector
Size	7.25 X 12 X 2.25 in
Weight	3.7 Lb (Approximate)
Power	28v @ 5w (Approximate)




Figure 3.2-1 SC-4 Single Board Spacecraft Computer Block Diagram

ORIGINAL PAGE IS  
OF POOR QUALITY


## RoMPS AMS Software Summary

<u>MODULE</u>	<u>VENDOR</u>	<u>FUNCTION</u>	<u>LANGUAGE</u>
VRTX-32	Ready Systems	Real Time Executive	"C", Assembler
RTL/86 VRTX-32	Ready Systems	"C" Reentrant Run Time Library Interface	"C", Assembler
RT-SCOPE	Ready Systems	System Monitor, Debugger	"C", Assembler
RTL/86 RT-SCOPE	Ready Systems	"C" Language Interface to RT-SCOPE	"C", Assembler
SC-4 Board Support Package	ICS/SpARC	Interface Between VRTX and SC-4 Devices	"C", Assembler
Command Input	SpARC	Get Command Packets from HH Avionics	"C"
Zymate Interface	SpARC	SCL to Zymate Interface	"C"
Telemetry Acquisition	SpARC	Acquire the Data of the Telemetry Items and forward to Telemetry Reduction	"C"
Telemetry Output	SpARC	Format and send telemetry	"C"

## RoMPS AMS Software Summary

<u>MODULE</u>	<u>VENDOR</u>	<u>FUNCTION</u>	<u>LANGUAGE</u>
SCL RTE	ICS	SCL Command Interpreter and Rules evaluation	"C"
Telemetry Reduction	ICS	Monitor Telemetry and post detected changes	"C"
Processing Scheduler	SpARC	Scheduled execution of scripts initiating EasyLab processing programs	SCL
Initiate Sample Processing	SpARC	Sends the EasyLab commands initiating sample processing	SCL
Initialize / Shutdown EasyLab	SpARC	Sends the EasyLab commands initiating/shutting down EasyLab	SCL
Send EasyLab Command	SpARC	Send an EasyLab Command	SCL

# AMS Memory Map




# RoMPS SC-4 EasyLab Software Summary

32

<u>MODULE</u>	<u>VENDOR</u>	<u>FUNCTION</u>	<u>LANGUAGE</u>
ZYOS	Zymark	Zymate Operating System	"C", PLM 86
Boot ROM	Zymark	Operating System Initialization	"C", PLM 86
Robot Module	SpARC	High level robot controller and servo interface	"C"
Annealer Module	SpARC	Oven controller interface	"C"
Annealer PyTechnology	SpARC	Annealer control variables and navigation routines	EasyLab
Rack Pytechnology	SpARC	Rack navigation routines and variables	EasyLab
Robot PyTechnology	SpARC	Robot control and navigation variables	EasyLab




# SC-4 EasyLab System Memory Map



**Processor Utilization**

- RoMPS sample thruput limited by annealing time
- Spacecraft Command Language  
Compiled script 300 lines/second
- EasyLab  
Interpreted procedure 10 lines/second
- Memory Margin 37 %

34d




ENGINEER	M.E. DOBBS	DRAFTSMAN	G. WASSICK
SPACE AUTOMATION & ROBOTICS CENTER		Block Diagram	1/2
ENVIRONMENTAL RESEARCH INSTITUTE of MI		GAS Canister Subsystem	
ANN ARBOR, MI		RoMPS	
		010-342	
		07/02/91	
		DATE	


HT HITCHHIKER TEMPERATURE SENSOR  
 RT RoMPS TEMPERATURE SENSOR

## Robot Control Subsystems

- 4 Degree-Of-Freedom Material Processing Robot
  - elevation, azimuth, reach, gripper axis
  - brushless dc motors
  - hall effect commutation
  - normally-on electrical brakes
  - quadrature output incremental position encoders
  - end-of-travel fiducials
  - current or force limited
  - compliant gripper
  - sequential operation
- Digital Servo Position Control
  - positioning accuracy       $\pm 0.025$  inch
  - velocity range              0.1 to 2.0 inches/sec
  - force limiting               $\pm 1$  lbf
  - Proportional-Integral-Derivative algorithm
  - $<5$  msec control loop cycle time
- PWM Drive Amplifier
  - chassis isolated output stage
  - 32 volt maximum phase voltage
  - 10 amp maximum phase current
  - fold-back current limiting
  - over-temperature protection
  - output inhibit



37



\* For loop 2 signal is differential

ENGINEER <u>L. M. Tomko</u>		DRAFTSMAN
SPACE AUTOMATION & ROBOTICS CENTER		Navtrol Controller Block Diagram
ENVIRONMENTAL RESEARCH INSTITUTE of MI		RMPS
ANN ARBOR, MI		DATE
Signal Ground <u>J3-1, J4-1</u>		Motor Power Vpp <u>J3-3, 15, J4-3, 15</u>
To Other Slave Programmable Servo Controllers (up to 6 more)		
Serial+ <u>J4-4</u>		
Serial- <u>J4-16</u>		

## Servo Axis Control Logic Suppliers

Functional Characteristic	Navtrol	Zymark	Industrial	uC
control algorithm	custom	custom	pid	pid
control loop rate	1.6 ms	5 ms	5 ms	5ms
number of channels/unit	2	6	1	1
commandable pid parameters	no, ucode	rom'd	yes	yes
trajectory mode	yes	no	no	no
cpu	32020	80186	several	NEC
embedded code rom'd	no	yes	yes	yes
edc ram	no	no	no	no
position detection	pot,incr	pot+incr	incr.	incr.
auxiliary inputs/outputs	yes/yes	yes/no	yes/yes	yes/no
standard functions	no	yes	yes	yes
interface library	no	yes	yes	yes
host i/o	AT bus	rs422	rs422	parallel
printed circuit board	smc	dip	dip	smc
temperature range	industrial	industrial	industrial	industrial
883	no	no	no	no
883 available 1:1	no	yes	no	no
industrial heritage	no	1800 units	yes	yes
flight heritage	pending	no	no	no
industrial cost	5k	tbd	2.5k	0.25k
mil-spec cost	na	na	na	na
883B cost	>200k	>50k?	na	na

Servo Axis Control Logic Suppliers


Functional Characteristic	Navtrol	Zymark	Industrial	uC
minimum modifications required	rom'd code, interface library of standard functions	10amp power drivers	workmanshi p	separate current amplifier




## Annealing Oven Control Subsystem

- Interfaces
  - Control serial interface
  - Feedback conditioned thermocouple output
  - Output quartz halogen filament lamp
  - Protection filament inrush protection
- Power Requirements
  - Voltage 24 volt rated lamp
  - Current 10 amp maximum
- Temperature Set Point
  - Range 350°C to 1500°C
  - Resolution  $\pm 2\%$  of setpoint (6 bits)
  - Repeatability  $\pm 2\%$  of setpoint (6 bits)
- Time Set Point
  - Range 3 to 7200 seconds
  - Resolution  $\pm 1$  second (software controlled)
- Response Time
  - limited by thermal coupling to sample
- Time Profile
  - 2 step time-temperature profile
    - 1) preheat, 2) melt

NAVROL  
MASTER




ENGINEER	M. E. Dobbs	DRAFTSMAN	G. Wassick
SPACE AUTOMATION & ROBOTICS CENTER			
ENVIRONMENTAL RESEARCH INSTITUTE of MI			
ANN ARBOR, MI			
Oven Control Block Diagram			DATE
RoMPS			08/13/91
Q10-343			DATE



ENGINEER	M. E. Dobbs	DRAFTSMAN	G. Wassick
SPACE AUTOMATION & ROBOTICS CENTER ENVIRONMENTAL RESEARCH INSTITUTE of MI			
ANN ARBOR, MI			
Oven Control Block Diagram RoMPS			10/10/91
010-344			08/13/91
			DATE

## Experiment Data Acquisition Subsystem

- RTA process monitor  
thermocouple lamp flux monitors
- Oven Status  
lamp current
- Robot Status  
4 axis position  
1 axis force  
EOT fiducials  
overtemp, current limit indicators
- Computer Status  
executive status  
script status  
rule evaluation
- Health and Safety Monitors  
radiator  
oven  
robot  
electronics stacks  
power supplies




ENGINEER	L. M. Tomko	DRAFTSMAN	Housekeeping Data Acquisition Block
			Diagram
			RoMPS
			010-338
			DATE
			10/10/91
			07/16/91

## RoMPS Data Acquisition List

A		B	C	D	E
1	RoMPS Data Acquisition				
2	Function	Description	Length	Rate	Comment
3					
4		sample temp	2	1	process
5		flux intensity	2	1	
6		flux intensity	2	1	
7		flux intensity	2	1	
8		flux intensity	2	1	
9		lamp current	2	1	
10		force	2	1	robot
11		eot status	2	1	
12		exp. current	2	1	engineering
13		elec temp	2	1	
14		elec temp	2	1	
15		radiator temp	2	1	
16		oven temp	2	1	
17		oven temp	2	1	
18		robot temp	2	1	
19					
20					
21					
22					
23					
24	TOTAL		30		


GAS Canister

Support Electronics Assembly



Note: The designation "P" means this connector is on the end of a cable.  
The designation "J" means this connector is on a chassis mount connector.  
PLUG JX IS 1553 OR nRS422

ENGINEER	L. M. Tomko	DRAFTSMAN	Interface Connectors
	SPACE AUTOMATION & ROBOTICS CENTER		Interface Connectors
	ENVIRONMENTAL RESEARCH INSTITUTE of MI		Interface Connectors
	ANN ARBOR, MI		Interface Connectors
		DATE	10/10/91
		DATE	06/07/91
		DATE	010-140



ENGINEER	M. F. Dobbs	DRAFTSMAN	
SPACE AUTOMATION & ROBOTICS CENTER		ROMPS OPERATIONAL CONCEPT	
ENVIRONMENTAL RESEARCH INSTITUTE of MI		ROMPS	
ANN ARBOR, MI		010-337	
		10/10/91	DATE